

SA-Monitor is a small program for reading data from Acrosport's TMD1 device.

Program usage:

Follow the instructions on the led screen of TMD control box to start the measurements.

Wait until the start of the first element and press «start» button. SA will show the results of measurements on the led screen and will forward them automatically to the computer. SA monitor will show current results at the left panel as soon as they will appear.

After the last element press «stop» button.

In the left panel you will see all information regarding current exercise. To select valid number of skills select the appropriate row in the left panel.

In the right panel you will see information about previously measured exercises. To see detailed information about previous exercise select it in the right panel.

You can add comment to the exercise (e.g. name of the person). To do that select the row of your interest, double click the cell in the «Comment» column, enter your comment and press Enter, or select another cell.

You can export all measured data to csv file (simple text format, can easily imported to excel). To do that select File>Export data to CSV.

To clear measured values select «File->New history file».

